1 Purpose

This procedure allows to determine the level of the noise, that is generated inside the reception chain. The noise level should be low and constant. An increasing noise level is an indication for the aging of a component.

2 Material

• SMA and BNC 50 loads

3 Test procedure

- 1. Terminate the IF input port at the back of the PC with a 50 load
- 2. Start the acquisition
- 3. Read the noise level on the spectra display of the control software
- 4. Check for spikes in the spectra
- 5. Stop the acquisition
- 6. Reconnect the IF input port
- 7. Terminate the IF input port of the Modulator, IF and Interface Unit (MII) with a 50 load
- 8. Start the acquisition
- 9. Read the noise level on the spectra display of the control software
- 10. Check for spikes in the spectra
- 11. Stop the acquisition
- 12. Reconnect the IF input port of the MII

Back to Maintenance Procedures; Go to RWP Maintenance in CWINDE;

1 Purpose 1